



Multi Objective Optimisation of an aeronautical vaporizer by coupling of Genetic Algorithms and CFD techniques

L. Bucchieri - Engin Soft M. Galbiati - Engin Soft P. DiMartino - Fiatavio



Presentation Outline



EST - Fiatavio Research Programme Optimisation concepts and strategy DOE, MOGA, RSM, ANN Basic CFD problem, design and logic setup Vaporiser initial run Parametrisation Design setup and logic **DOE and MOGA screening** SOBOL screening MOGA high mutation generations **MOGA and RSM optimisation** Response surface fitting MOGA and RSM blending Runs MCDM final design



RESEARCH PROGRAMME



- Partners: Engin Soft Trading CAE company, FIATAVIO aerospace, University of Trieste
 - Develop a programme to link CFD techniques and optimisation techniques.
 - needing the exploration of a wide range of variability for the design parameters
 - involving several aspects (MULTIDISCIPLINARY)
 - with several, may be conflicting, objectives (MULTIOBJECTIVE)
 - respecting the "computation budget" available for problems involving high CPU demands ie. 3D RANS CFD
 - Develop parametric test models:
 - gas turbine rotor blade
 - shroud sealing flows
 - fuel vaporiser (Fiatavio supplies a typical vaporiser design to be optimised within the framework of technological innovation of the combustor product)



Optimisation



- Optimisation techniques can roughly be divided in three classes
 - screening techniques: DOE (Design Of Experiment) methods which are intelligent ways to minimize the experiments getting the maximum of information out of them
 - Gradient or Genetic Algorithm techniques to:
 - find the optimal solution on a N-dimensional surface with gradient methods
 - find the optimal solution after N-generations of genetically selected experiments
 - 1nterpolating techniques
 - Finding optimal solution without running CFD analysis, but on an interpolating surface of previously run solutions: RSM (Response Surface Method)
 - Finding optimal solution without running CFD analysis, but on an interpolating neural network of transfer functions between input parameters and output objectives: ANN (Artificial Neural Networks)



FRONTIER Product Properties



ALL platforms are supported **Decision Support tools Browser based technology** Pareto Filters JAVA,CORBA,XML) MCDM Statistical charts Capability of handling any computing Parallel charts services files or API (Application Protocol The order of magnitude is: Interface) ... 100 analysis automatic analysis from CFD to MS-EXCEL for typically 20 variables, 3 objectives, 3 constraints **Optimisation Algorithms Multi-Objective Genetic Algorithm**, **Simplex** FRONTIER allows the user to **Gradient based methods** extract the maximum of **DOE (Design of Experiments)** information allowed by the user-RSM defined CPU budget ANN



Basic CFD



- ☐ Set up in CFX4.3:
 - geometry 3d in cylindrical coordinates
 - fully compressible model
 - mass fraction 1 for vaporised fuel
 - mass fraction 2 for recirculating products from combustor can
 - lagrangian tracking for particle phase
 - spray model employed with turbulent dispersion
 - Reynolds Stress Model for turbulence
 - Two numeric procedure to guarantee convergence
 - 15 X 100 it with k-epsilon
 - 15 X 100 it with RSM but restart from K-epsilon
 - 100 maximum down to 50 minimum fluid iterations for each particle coupling, dynamically set by USRCVG



Basic CFD




- Boundary conditions
- Inlet 1
 - **↑** T = 900 Kelvin
 - Air mass flow = 40% total
 - **Swirl angle = 40 degrees**
- Inlet 2
 - **T** = 900 Kelvin
 - Air mass flow = 60% total
 - **Swirl angle = 40 degrees**
- Atomiser (fuel droplet inlet)
 - SMD 45 microns
 - Rosin Rammler exponent 3.0
 - Fuel/Air mass flow ratio = 5.0%



Basic CFD









Design Problem




- The basic fuel vaporiser must be improved:
 - inlet air and fuel mass flow are given
 - inlet swirl angles and air mass ratios are free
 - dimensions are limited
 - nessure drop must be minimised
 - recirculation must minimised
 - fuel vaporisation must be maximised
 - 1 length must be minimised
 - recirculating combustion products must not go upstream the throat
 - swirl number at exit is set to combustor requirements Sw_{no}=0.50
 - convergence must be obtained



Design Problem









Input parameters


	Definition	Original	Minimum	Maximum
L1	Length channel 1	7.0	2.0	15.0
L2	Lengtht channel 2	7.0	2.0	15.0
B1=-B2	Increase Width channel 1	0.0	0.0	5.0
	= decrease width cahnnel 2			
Delta R1	Throat radius reduction	0.0	0.0	3.0
Length	Length diverging duct	15	10	30
Alfa1	Swirl angle channel 1	40.0	10	80
Alfa2	Swirl angle channel 2	40.0	10	80


Note: b1 and b2 change the area hence the mass flow rate ratios from the pressure plenum



The fast ode as illustrated in the following chart:



















```
#!/bin/sh
cp /users/engin/FRON/inizio_copiami.db ./inizio.db
cp /users/engin/FRON/m01.f.
runbuild4 -b -sfp cfxbuild4.ses.01
mv *geo* m01.geo
runmi -cylaxis -fe m01.geo
rm m01.geo inizio.db*
mv *geo* m01.geo
rm setting* volm* cfxbuild4.ses.02
runsolve4 -f m01.f -c m01.fc -g m01.geo -enviro 01
runsolve4 -f m01.f -c m03.fc -g m01.geo -r m01.dmp -enviro 03
cp ./m03.dir/param .
cp ./m03.dir/CONVERGENZA .
rm -r m01.dir m03.dir m01.fo *.trk m01.dmp *.log file*
compress *.*
```












with 7 input parameters running a 3 level full factorial DOE (min, med,Max) would mean 3⁷=2187 experiments!!!!! Or CFD analysis!!!


DOE reduction methods


- **Box-Benhkem**
- 1 Taguchi
- MonteCarlo
- **Random**
- **SOBOL** (a uniform Random)















In a 7 input parametric space with 5 objectives, needs 40-50 experiments for just a basic screening

MOGA


- Multi Objective Genetic Algorithm searches for optimal solution after N-generations of genetically selected individuals by:
 - selection
 - cross-over
 - **mutation**

SOBOL and MOGA

- A first generation of 20 experiments (CFD analysis) is produced "randomly" in a SOBOL sequence
- MOGA runs 3 generation with high (respect to standard) mutation coefficient: 30%, hence 6 out of 20 experiments mutate each generation
- Total of 80 experiments are run: 20 are screening randomly, the other 60 evolute toward the optimal solutions with a mutation for 18 experiments
















Final Optimisation




Parameter reduction

- The length of the inlet channels are fixed, since they do not heavily influence the output.
- Pressure loss is not considered an objective, since the pressure requirements can always be satisfied.
- The length parameter is extended to 50 mm
- Swirl number deviation is changed into a constraint
- 2 input parameters and 1 objective are eliminated
- 1 Logic is reduced

- Response surface is fitted and trained to reduce CPU time
- Multi Criteria Decision Method post-processing
 - MCDM functions are introduced to postprocess the final design
 - weight of 3 objectives to obtain a single objective







RSM - MOGA



MOGA RSM Blending


- The final optimisation is run on a blend of:
 - **75% RSM virtual**
 - 25% MOGA real experiments

MOGA setting

4 generations of 20 experiments

RSM blend

- 10 generations of 20 experiments
 - 50 real
 - **150 virtual**
- is re-trained and updated each generation
- Total CPU time is reduced of 50%







RSM Fitting



RSM RSM

- On the 80 experiments SOBOL-MOGA, a response surface is fitted so that experiments can be performed virtually on the N -dimensions response surface instead of going through an explicit CFD run
- Basically an experiment on a RSM has CPU time of less than 1 sec while the average CFD run takes 90 minutes:
 - **Advantage: ENORMOUS CPU TIME SAVING**
 - Disadvantage: Response Surface must have low errors and virtual results (if chosen)must be validated by CFD








RSM Confidence



□ RSM


- a fitting is performed by gaussian interpolation
- the errors are checked on all real experiments
- sample surface on %fuel vaporised at 4th generation





Parallel Chart Convergence








Parallel chart postprocessing








MCDM Postprocessing




☐ Weights are introduced for each output variable

Marked	First Attribute	Туре	Weight	Second Attribute
V	swirl_no	greater than	2.0	ray_out
V	fuel	greater than	1.5	length
V	swirl_no	equal to	1.0	fuel
V	mass_rec	greater than	3.0	length

Non linear weighing functions are computed







MCDM postprocessing



Design ranking

Design No.	length	mass_rec	fuel	swirl_no	ray_out	Rank Value
45	45.0	0.0	75.59436	0.2180011	0.00907218	0.696718006342
18	49.0	0.9883296	72.13689	0.0544705	0.0106934	0.693395846394
2	40.0	73.97912	72.97001	0.0462573	0.00996328	0.690309713192
5	15.0	34.89241	39.2496	0.2459233	0.0106934	0.686747862539
29	15.0	25.74149	39.1771	0.2476789	0.0103283	0.685246411073
68	45.0	1.36824	67.624	0.0851953	0.0110585	0.684698460919
260	49.5	-5.083780795681	65.730085808563	0.0488729864080	0.0085448456882	0.681538510871
64	45.0	0.0	64.13435	0.109817	0.00961084	0.678128166238

Design 260 is virtual on RSM: if chosen must be validated



FINAL Design CFD



Design	Length	% Fuel Vap.	Δ Swirl NO.	Recirculation	Rec. Radii
1 Real	30.00	41.10%	0.077	0.00	0.096
260 Virtual	49.50	65.71%	0.048	-5.08	0.085
260 Real	49.50	69.72%	0.047	0.00	0.09





MAS\$_FRACTIONI

- 6.000E-02
- 5.700E-02
- 5.400E-02
- 5.100E-02
- 4.800E-02
- 4.500E-02
- 4.200E-02
- 3.900E-02
- 3.600E-02
- 3.300E-02
- 3.000E-02
- 2.700E-02
- 2.400E-02
- 2.100E-02
- 1.800E-02
- 1.500E-02
- 1.200E-02
- 9.000E-03
- 6.000E-03
- 3.000E-03





Conclusion



- ☐ 3 Objectives have been simultaneously chased
 - minimising recirculating radii
 - minimising length
 - maximising % vaporised fuel
- Two main goals are obtained
 - Tlashback is avoided (constraint of recirculation combustor products)
 - Desired swirl number is obtained
 - It means that a tuning of 2 mass flow rates and 2 swirl angles can make the same vaporiser yield different swirl numbers for different combustor can requirements
 - It has been tested with success on two similar vaporisers chasing different swirl numbers